

INSTALLING THE STRAIGHT CABLE KIT

- 1.- Remove the rubber bumper from the bottom of the boom.
Insert the cable into the boom from below and pull it out through the slit in the tip.
- 2.- Push the supplied foam rubber tube through the slit.
- 3.- Wind the cable ½ turn around the tip, push it through the tube and pull it through around 40 cm. It is easier if you apply some grease or silicon oil to the cable.
- 4.- Mount the supplied XLR-3F (or XLR-5F for stereo) connector to the cable.
Wiring for mono is:
ground / shield = XLR-3F pin 1
red = XLR-3F pin 2
blue = XLR-3F pin 3
Wiring for stereo (grey cap) is:
ground / shield = XLR-5F pin 1
brown = XLR-5F pin 2
green = XLR-5F pin 3
yellow = XLR-5F pin 4
white = XLR-5F pin 5
- 5.- Pull the lower end of the cable with the XLR-3M connector through the supplied metal end piece so the cable comes out at the end.
- 6.- Screw the endpiece to the boom applying some of the supplied grease.
- 7.- Pull the cable out through the sideward outlet of the endpiece.

