

## Mounting instructions for the QP 120 Extension

1. unscrew the handnut from the QP 120 extension and slide it over the last segment of your QP boom pole.
2. take the POM compression ring off the QP 120 and slide it over the QP boom.
3. slide the QP boom into the extension.
4. seat the compression ring in position.  
**TAKE CARE THAT THE METAL PIN IS IN THE SLOT OF THE RING, OTHERWISE IT WILL GET BENT AND DAMAGE THE COMPRESSION RING AND THE TREADS OF THE HANDNUT!**
5. screw on the handnut – done.
6. If wanted, you may mount a piece of velcro (supplied) around the foot of the QP boom just above the metal end piece to make it fit tight and rattle free. Clean the surface free of fat or dust before attaching the self-adhesive velcro.

